

Commercial organisations are charged the recommended retail price. If the purchasing organisation is using the equipment for a sport based activity and makes **NO** financial gain from the events or activities for which the equipment is used, **most** of the prices shown below will be discounted by about 15%. Examples of **Not for Profit** organisations are amateur sports clubs, schools and colleges of further education. Organisations based **outside UK/Republic of Ireland** should contact us for pricing information. Prices are subject to change without notice and are affected by currency fluctuations. Carriage/Insurance is charged at cost.

Hardware Prices as at 13/05/2019	Recommended Retail Price		Discounted Price	
	£	£ ExVAT	£	£ ExVAT
SI-Cards - Also View/Purchase Individual SI-Cards online at www.sportident.co.uk				
Trade-in an SI-Card or Emit brikke (Credit against an SI-Card purchase in our online shop)	-3.00	-2.50	-3.00	-2.50
SI-ActiveCard incl. Elastic Finger Loop (128 Punches). Contactless and Direct punching. Includes Battery	73.94	61.62	62.86	52.38
ComCard Pro. Combines an SI-Card 10 chip (128 punches) and a Moscow 2, 3, 8 or 9 Compass	99.49	82.91	84.57	70.48
ComCard Up. Combines an SI-Card 8 chip (30 punches) and a Moscow 11 Compass	65.88	54.90	56.00	46.67
SI-Card 10 incl. Elastic Finger Loop (128 Punches. Suitable for use at all major worldwide events)	56.47	47.06	48.00	40.00
SI-Card 9 incl. Elastic Finger Loop (50 Punches. Suitable for use at all major worldwide events)	44.36	36.97	37.71	31.43
SI-Card 8 incl. Elastic Finger Loop (30 Punches. Suitable for use at all major worldwide events)	33.61	28.01	28.57	23.81
SI-pCard - Needs an Attachment (20 punches. 55mm x 55mm x 1mm. Not ideal for competitive events)	13.44	11.20	11.43	9.52
Yoyo. Attach your SI-Card to the yoyo. Attach the yoyo to your bike or your clothing	3.83	3.19	3.26	2.71
Keyring. Attach your SI-Card to a Keyring	0.14	0.12	0.12	0.10
Spare Lanyard which can be attached to your SI-Card or SI-pCard	1.98	1.65	1.68	1.40
Spare Elastic 14cm Finger Loop for SI-Card 8/9/10/SIAC - Black (used only for orienteering)	1.98	1.65	1.69	1.41
Spare Elastic 25cm Wristband for all SI-Card - Black	2.48	2.07	2.11	1.76
Wristband – Tyvek ultra-strong, Tamperproof, one use only. Strip of 10	1.20	1.00	1.20	1.00
SI-Card Security Cord	2.11	1.76	1.80	1.50

Hardware Prices as at 13/05/2019

Recommended Retail Price

Discounted Price

£

£

ExVAT

£

£

ExVAT

[See The Online Catalogue](#)

Stations - Clear/Check/Start/Control/Finish

Station BSF7-D (Display Bottom) - Black	114.29	95.24	97.14	80.95
Station BSF8-DB (Display Bottom) Red	112.94	94.12	96.00	80.00
Optional Semi-permanent Label (Station Code) for top of BSF8 Station - Black on White background	0.88	0.73	0.74	0.62
SI-Master BS8DT Blue. Timemaster & BSF8 Station Combined	174.79	145.66	148.57	123.81
BS11-BL (Beacon Large for touch free punching. Typical use MTB Enduro stage Finish)	403.36	336.13	342.86	285.71
BS11-BS (Beacon Small for touch free punching. Typical use MTB Enduro stage Start)	201.68	168.07	171.43	142.86

Download/Wired Stations

Master station BSM7-RS232 with 1.5M lead. Stores 1000 SI-Card in Backup Memory and connects to PC - Red. (Not suitable for preparing or reading backup from the old BS3/4/6 stations)	130.42	108.68	110.86	92.38
Master station BSM7-RS232 with 5M lead. Stores 1000 SI-Card in Backup Memory and connects to PC - Red. (Not suitable for preparing or reading backup from the old BS3/4/6 stations)	133.10	110.92	113.14	94.29
SPORTident Serial/USB Converter - A BSM7-RS232 Masterstation or Serial Printer can be plugged into a USB Port	38.99	32.49	33.14	27.62
Master station BSM7-USB. Stores 1000 SI-Card in backup memory and connects to PC. (Cannot be used as a radio control or for preparing or reading backup from the old BS3/4/6 stations)	121.01	100.84	102.86	85.71
Master station BSM8-USB. Stores 1000 SI-Card in backup memory and connects to PC. (Cannot be used as a radio control or for preparing or reading backup from the old BS3/4/6 stations)	114.29	95.24	97.14	80.95
Station BSF8-SRR-DB (Display Bottom) - Blue or Red	174.79	145.66	148.57	123.81
SRR USB Dongle	38.99	32.49	33.14	27.62
Purple SERVICE/OFF Off Card for Activating/switching off stations	12.44	10.37	10.58	8.82
Coupling Stick for joining a Masterstation & Basestation and enhancing the field between the two	7.32	6.10	6.22	5.18
Purple Switch On/Off Stick for BS11 Beacons	12.44	10.37	10.58	8.82
Purple Clear Backup Card for clearing the memory in Masterstations and Basestations	12.44	10.37	10.58	8.82

Starter/Full Training Sets - Can be used without a computer

Starter Set - 20 SI-pCard, 3 BSF8 Stations (CLEAR/SI-Master, START, FINISH station), AP1310 Printer Set, Coupling Stick	1163.03	969.19	988.70	823.81
Full Set - 20 SI-Card 8, 13 BSF8 Stations (CLEAR/SI-Master, START, 10 Control, FINISH station), AP1310 Printer Set, Coupling Stick	2656.24	2213.53	2257.80	1881.50
Full Set - 20 SI-Card 9, 13 BSF8 Stations (CLEAR/SI-Master, START, 10 Control, FINISH station), AP1310 Printer Set, Coupling Stick	2898.68	2415.57	2463.88	2053.23
Full Set - 20 SI-Card 8, 13 BSF7 Stations (CLEAR/SI-Master, START, 10 Control, FINISH station), AP1310 Printer Set, Coupling Stick	2648.08	2206.73	2250.86	1875.72
Full Set - 20 SI-Card 9, 13 BSF7 Stations (CLEAR/SI-Master, START, 10 Control, FINISH station), AP1310 Printer Set, Coupling Stick	2891.58	2409.65	2457.84	2048.20

Original Printer Set - includes Able AP1310 Thermal Printer & Printout Station (see below) with gender changer allowing attachment to a computer, Serial/USB Converter, Service/OFF Card, Clear Backup Card, Start Card, Print Results Card, carry case 340x275x83mm

717.43 597.86 609.81 508.18

Able AP1310 Thermal Printer - includes Internal Short life rechargeable battery & AC Adapter, RS232 lead ,rolls paper. Fully charged battery prints at least 150 splits prints

254.11 211.76 216.00 180.00

Printout Station BSM7-P RS232. Used with AP1310, MCP7830, GPT-4378 & DPU-3445 printers. Also as a Masterstation with a PC

340.33 283.61 289.28 241.07

Printout Station -> Computer Gender Changer & Null Modem Mini Connector

5.29 4.41 4.50 3.75

Purple START Card. Sets a mass start time (no-punch) in a Printout Station for the next SI-Cards

12.44 10.37 10.58 8.82

Purple PRINT RESULTS Card for printing results from a Printout Station

12.44 10.37 10.58 8.82

SPORTident Orienteering App Set (includes BSM8-USB, SPORTident Red Printer, 2 Adapter Cables)

238.80 199.00 238.80 199.00

SPORTident Little Red Printer

118.80 99.00 118.80 99.00

USB OTG to USB Adapter: Connect a BSM7 or BSM8 station to an Android device with a Micro-USB connector (for SPORTident Red Printer)

7.20 6.00 7.20 6.00

USB-C to USB Adapter: Connect a BSM7 or BSM8 station to an Android device with a USB-C connector (for SPORTident Red Printer)

7.20 6.00 7.20 6.00

SPORTident Printer Serial Cable: Connect the SPORTident Printout Station BS7-P to the SPORTident Printer

10.80 9.00 10.80 9.00

Hardware Prices as at 13/05/2019

	Recommended Retail Price		Discounted Price	
	£	£ ExVAT	£	£ ExVAT
Fast Thermal Printers & Paper Rolls - Prices Include Installation Support				
Epson TM-T20 USB Thermal 80mm Split time Printer. <i>Amazingly fast</i> Point of Sale Printer	180.00	150.00	180.00	150.00
Thermal Printer Paper Roll 80mm width x 80mm diameter for Epson/Citizen/Star POS printers	2.64	2.20	2.64	2.20
Thermal Printer Paper Roll 57.5mm width x 31mm diameter for GeBe GPT-4378 printer	1.08	0.90	1.08	0.90
Thermal Printer Paper Roll 57.5mm width x 46mm diameter for Able AP1310 and Martel MCP7830 printer	1.15	0.96	1.15	0.96
Accessories				
2.5MM Allen Key for removing plastic bottom plate of a BS7/11 station	2.47	2.06	2.10	1.75
1.5MM Allen Key for removing metal bottom plate of a BS8 station	2.47	2.06	2.10	1.75
2.5MM hex bit for electric screwdriver/drill to remove plastic bottom plate on a BS7/11 station	2.47	2.06	2.10	1.75
Replacement rubber Ring (set of 2) for sealing between base and cover on a BS7 Station	2.72	2.27	2.32	1.93
Replacement Nut for attaching cover to base of BS7 station	0.13	0.11	0.11	0.09
Replacement Bolt for attaching cover to base of BS7 station	0.13	0.11	0.11	0.09
Station Box BS7 Transparent, including bottom plate	6.41	5.34	5.45	4.54
Station Box BS8 Blue or Red, including bottom plate	5.99	4.99	5.09	4.24
Shielding foil BS7 in Black, Red or Red/Blue	2.10	1.75	1.79	1.49
Power Supply Unit for UK use in MCP7830 Printer Set, Special Start/Finish	18.22	15.18	15.48	12.90
Power Inverter 300 Watt. Converts 12V DC from Car/Leisure Battery to Mains 240 Volt.	69.43	57.86	69.43	57.86
6 Port USB Charger & USB Leads	62.11	51.76	52.80	44.00
BS7 Metal Bottom Plate – security plate allows a base station to be securely wired to an immovable object	6.16	5.13	6.16	5.13
BS8 Fitted Metal Bottom Security Plate 1 – Allows a base station to be securely wired to an immovable object	8.26	6.88	8.26	6.88
BS8 Fitted Metal Bottom Security Plate 2 – As for Plate 1 but unit can be seated in a BSF7 holder on a stake	8.26	6.88	8.26	6.88
Wire Strop for securing Bottom Plate 3MM diameter x 1Metre length. With plastic end caps	2.87	2.39	2.87	2.39
Wire Rope Grips for 3 - 5 MM diameter strop with 8MM Nut. Creates a reasonably secure loop in the wire	1.60	1.33	1.60	1.33
8MM Combination Spanner for tightening/loosening a wire rope grip with 8mm nut	5.04	4.20	5.04	4.20
BS8 Station Metal Plate and two tamper proof bolts that secure a station permanently to an immovable object	12.30	10.25	10.45	8.71
Lightweight hardened alloy 'L' stake, drilled so that plastic station holder and pin punch may be attached. Wt 400gm excl. Holder, height 75cm above ground	14.11	11.76	12.00	10.00
Glass Fibre stake (yellow). Station holder can be attached. Wt. 100gm excl holder, height 68cm above ground. One sliding clip on shaft. Pin punch needs to hang on a cord from stake	16.94	14.12	14.40	12.00
Extra Plastic sliding clip for shaft of glass fibre stake	1.78	1.48	1.51	1.26
Plastic Narrow Mounting for BS7 Station with no bolt/screw holes	2.63	2.19	2.23	1.86
Plastic Narrow Mounting for BS8 Station with no bolt/screw holes. Snaps into BS3/4/6/7 Plastic Narrow Mounting	2.63	2.19	2.23	1.86
Plastic Holder for BS7 Station with two bolt/screw holes. Attaches to stake or structure	4.42	3.68	3.75	3.13
Plastic Holder for BS8 Station with two bolt/screw holes. Attaches to stake or structure	3.66	3.05	3.11	2.60
Plastic Holder for BS8 Station with two bolt/screw holes. Snaps into Plastic Holder for BS3/4/6/7. Also attaches to stake or structure	5.27	4.39	4.48	3.73
Orienteering Kite - Superior Reinforced Mesh with strong wire frame, 30cm x 30cm	7.67	6.39	6.51	5.43
Orienteering Kite - Superior Reinforced Mesh with strong wire frame, 15cm x 15cm	6.05	5.04	5.14	4.29
Pin punch to attach to stake	4.34	3.62	3.70	3.08
Set of 4 Lightweight Cones 45cm with velcro tape for top. BSF8 Stations are attached for gymnasium use	37.12	30.93	31.55	26.29
Carrying Vest for 16 BSF7 SPORTident Stations (not suitable for BSF8)	35.29	29.41	30.00	25.00
Carrying Belt for 8 BSF7 SPORTident Stations (not suitable for BSF8)	24.00	20.00	20.40	17.00
Grey Carry Case Small (391x304x104mm) - Includes Liner. Holds approx. 20 BSF7 or 50 BSF8 Basestations loose	28.91	24.09	24.57	20.47
Foam Insert for Grey Carry Case Small (391x304x104mm) - Holds 60 SI-Cards	16.24	13.53	13.80	11.50
Foam Insert for Grey Carry Case Small (391x304x104mm) - 18 BSF8	17.58	14.65	14.94	12.45
Foam Insert for Grey Carry Case Small (391x304x104mm) - School & Training Set	17.58	14.65	14.94	12.45
Grey Carry Case Medium (575x470x270mm) - Includes Foam Station Insert	106.22	88.52	90.29	75.24

Hardware Prices as at 13/05/2019

	Recommended Retail Price		Discounted Price	
	£	£ ExVAT	£	£ ExVAT
Hire of Equipment & Optional Prep of Stations/SI-Cards. Minimum Hire Charge Excl. Losses/Carriage £50+VAT				
SiTiming Software Single Day Licence - Available on expiry of a previously purchased licence	50.64	42.20	42.00	35.00
Laptop with SiTiming & Thermal Printer Drivers pre-loaded. Single Day Use	48.00	40.00	48.00	40.00
Training Set - 20 SI-Card 8, 13 BSF8 Stations (Clear/SI-Master, Start, 10 Control, Finish station), Printout Station/Printer Set	132.00	110.00	132.00	110.00
SI-Card 8 One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	2.29	1.91	2.29	1.91
SI-pCard One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	2.29	1.91	2.29	1.91
SI-Card 5 One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	2.29	1.91	2.29	1.91
SI-Card 9 One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	2.93	2.44	2.93	2.44
SI-Card 6 One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	3.54	2.95	3.54	2.95
SIAC One Day use. Click For Significant Discounts If ALSO Using SiEntries and/or SiTiming	4.32	3.60	4.32	3.60
Elastic 14cm Finger loop (washed). Used mainly for orienteering events	0.12	0.10	0.12	0.10
Elastic 25cm Wristband (washed). Used mainly for non-orienteering events	0.12	0.10	0.12	0.10
Tyvek one use wristband, tamperproof. Used mainly for non-orienteering events	0.12	0.10	0.12	0.10
Lanyard which can be worn round the neck and attached to your SI-Card or SI-pCard	0.12	0.10	0.12	0.10
Optional Additional Service - Each SI-Card is Provided CLEARed & CHECKed	0.05	0.04	0.05	0.04
Optional Additional Service - Each SI-Card has a one-use wriststrap attached. Strap must be purchased separately	0.10	0.08	0.10	0.08
Optional Additional Service - Numbering SI-Card Straps (not usually necessary)	0.04	0.03	0.04	0.03
Control Station (BSF7 or BSF8) daily use	6.00	5.00	4.80	4.00
Beacon Station Small (BS11-BS Blue) daily use	11.38	9.48	9.10	7.58
Beacon Station Large (BS11-BL Large) daily use	22.72	18.93	18.17	15.14
Masterstation (BSM7-RS232 or BSM7-USB) daily use	6.60	5.50	5.40	4.50
Control and Masterstation Station Optional Preparation - Programme and Label	0.48	0.40	0.48	0.40
Metal Bottom Plate Attached to BSF7 Station	1.08	0.90	1.08	0.90
Wire Strop for securing Bottom Plate & Rope Grip. 8MM Spanners included if required	0.84	0.70	0.84	0.70
Lightweight hardened alloy 'L' stake or Yellow Fibre Stake with plate to Hold a Control Station	2.33	1.94	2.33	1.94
36mm Semi-Permanent Label suitable for the period of a hire, displaying a Control Code. Attaches to each side of the angle plate of a metal stake or the top of a station	0.50	0.42	0.50	0.42
Orienteering Kite - Nylon, 30cm x 30cm	1.20	1.00	1.20	1.00
Start/Finish Station BS7-S - connects to lightbar or manual switch and PC using 15M serial leads	15.84	13.20	15.84	13.20
Photoelectric Lightgate Barrier & Pair of tripods	60.30	50.25	60.30	50.25
Epson TM-T88 USB Thermal Split time Printer. Amazingly fast Point of Sale Printer.	18.00	15.00	18.00	15.00
Thermal Printer for use with Printout Station - includes Internal Short life rechargeable battery	18.00	15.00	18.00	15.00
Thermal Printer Set - includes Thermal Printer & Printout Station, Service/OFF Card, Clear Backup Card, Start Card, Print Results Card	35.00	29.17	35.00	29.17
Unleaded Petrol Generator and long power lead for external use. Petrol not included. Daily Use	30.00	25.00	30.00	25.00
Upgrades/Repairs				
Warranty Repair	FREE	FREE	FREE	FREE
Firmware upgrade for SPORTident BS7/8 stations	3.10	2.58	3.10	2.58
Inspection Fee - No Fault Found. Includes O-ring Seals (BS7/BS8) & Firmware Upgrade	10.56	8.80	10.56	8.80
Battery Replacement - BS7/8. Includes O-ring Seals & Firmware Upgrade	18.00	15.00	18.00	15.00
Removal/Fitting of BSF8 Permanent Metal Baseplate during station inspection/repair	2.40	2.00	2.40	2.00
Out of Warranty BS7/8 Station Repair. Includes O-ring Seals & Firmware Upgrade	24.00	20.00	24.00	20.00
Out of Warranty BS7/8 Station Repair & Battery Replacement. Includes O-ring Seals & Firmware Upgrade	31.20	26.00	31.20	26.00
SI-Card Label (per label for 5 or less)	1.20	1.00	1.20	1.00
SI-Card Label (per label for 6th or more)	0.24	0.20	0.24	0.20
Out of Warranty SI-Card Repair or Replacement of Plastic Parts. If not repairable, see SI-Card purchase options above	13.91	11.59	13.91	11.59
Warranty - Faulty Goods Should Be Returned to SPORTident UK Ltd.				
SI-Card 8/9/10 (5 year), SI-pCard (2 year) chip failure warranty. Warranty does not cover breakage of plastic parts				
SIAC: 2 years circuitry failure. Warranty does not cover battery and breakage of plastic parts				
Control/Masterstations: 2 years warranty. Stations are water-resistant but cannot be immersed in water. Opening a station without prior agreement with SPORTident UK invalidates the warranty.				
Printers: 1 year warranty				
Consumables (elastic finger loops, wristbands, Yoyos): No warranty				